



JOYANCE SPRAYER DRONES: RECOMMENDED SPARE PARTS LIST

JT-6L-606	
Name	Quantity
Motor	1
Water tank	1
Nozzle body	2
Nozzle 0.075	2
Nozzle 0.15	4
Hose	1
Propeller	2
Folding joint	2
ESC	1
Quick release prop adapters	6
GPS stand	2
Motor mount	2
Landing leg	4
Connector of leg to board	8
Arm (carbon fibre tube)	2
Water pump	1

JT-10L-608	
Name	Quantity
Motor	2
Water tank	1
Nozzle body	2
Nozzle 0.075	2
Nozzle 0.15	4
Hose	1
Propeller	4
Folding joint	2
Middle connecting joint	2
ESC	1
ESC	1
ESC	1
Quick release prop adapters	8
GPS stand	2
Motor mount	2
Landing leg	4
Connector of leg to board	8
Short arm (carbon fibre tube)	1
Long arm (carbon fibre tube)	1
Water pump	1

JT-10L-606	
Name	Quantity
Motor	2
Water tank	1
Spraying nozzle	2
Hose	1

Propeller	4
Folding joint	2
ESC	2
Quick release prop adapters	6
GPS stand	2
Motor mount	2
Landing leg	4
Connector of leg to board	8
Arm (carbon fibre tube)	1
Water pump	1

JT-15L-608	
Name	Quantity
Motor	2
Water tank	1
Nozzle body	2
Nozzle 0.075	2
Nozzle 0.15	6
Hose	1
Propeller	4
Folding joint	2
Middle connecting joint	2
ESC	1
ESC	1
ESC	1
Quick release prop adapters	8
GPS stand	2
Motor mount	2
Landing leg	4
Connector of leg to board	8
Short arm (carbon fibre tube)	1
Long arm (carbon fibre tube)	1
Water pump	1

JT-15L-606	
Name	Quantity
Motor	2
Water tank	1
Spraying nozzle	2
Hose	1
Propeller	4
Folding joint	2
ESC	3
ESC of nozzle	2
Quick release prop adapters	6
GPS stand	2
Motor mount	2
Landing leg	4
Connector of leg to board	8
Arm (carbon fibre tube)	1
Water pump	1